

Do It Yourself - Hard Case Plans

To Cushion inside of case with felt (available at most Fabric Stores), rip felt to 7-3/4" wide. Fasten to plywood sides before assembly using 3M-77 spray adhesive (also at Fabric Store). Cut ends long enough to fold back onto opening ends sides. Glue and nail, staple or screw, 1/4" plywood to 1x edge pieces.

